

Термометр сопротивления

WT-BB perf

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884


Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

WT-BB perf.

AIR-DUCT RESISTANCE THERMOMETER

WITH EXCHANGEABLE INSERT



COMPLETE INSTRUMENTS

SPECIFICATION OF THE STANDARD DESIGN:


- + Connection head type B at light metal with cable gland M 20 x 1,5 (acc. to DIN EN 50446)
- + Thermowell and lagging tube at stainless steel 1.4571
- + Mounting bush G 1/2 (BSP) at stainless steel 1.4571
- + Immersion length EL acc. to table
- + Lagging tube length HL = 145 mm
- + Thermowell perforated over a length of 45 mm
- + Insert with rigid protection tube at stainless steel (acc. to DIN 43735)
- + Resistor 1x Pt100 or 2x Pt100 acc. to DIN EN 60751 class B (ceramic resistor with bifilary wire winding)
- + 2-, 3- or 4-wire connection
- + Connection via ceramic terminal block with connection pins
- + Range -30 °C to 300 °C

SPARE INSERTS AT STANDARD DESIGN

SPECIFICATION:

+ See the standard design

	Insert ø mm	Insert Length in mm	2-Wire Connection		3-Wire Connection		4-Wire Connection	
			1x Pt100	2x Pt100	1x Pt100	2x Pt100	1x Pt100	2x Pt100
WT-ME-6	6	315	7661044	7661144	7661244	7661344	7661444	-
		405	7661046	7661146	7661246	7661346	7661446	-
		455	7661049	7661149	7661249	7661349	7661449	-
		555	7661050	7661150	7661250	7661350	7661450	-
WT-ME-8	8	315	7661074	7661174	7661274	7661374	7661474	7661574
		405	7661076	7661176	7661276	7661376	7661476	7661576
		455	7661079	7661179	7661279	7661379	7661479	7661579
		555	7661081	7661181	7661281	7661381	7661481	7661581



Thermowell & Lag- ging Tube ø mm		Material	Immersion Length in mm	Insert ø mm	Insert Length in mm	2-Wire Connection		3-Wire Connection		4-Wire Connection	
WT-BB-9 perf.	9	1.4571 X6CrNiMoTi 17-12-2		6		1x Pt100	2x Pt100	1x Pt100	2x Pt100	1x Pt100	2x Pt100
			160		315	7661011	7661111	7661211	7661311	7661411	-
			250		405	7661012	7661112	7661212	7661312	7661412	-
			300		455	7661013	7661113	7661213	7661313	7661413	-
WT-BB-11 perf.	11		400	555	7661014	7661114	7661214	7661314	7661414	-	
			160	315	7661031	7661131	7661231	7661331	7661431	7661531	
			250	405	7661032	7661132	7661232	7661332	7661432	7661532	
			300	455	7661033	7661133	7661233	7661333	7661433	7661533	
		400	555	7661034	7661134	7661234	7661334	7661434	7661534		

OPTIONS (Order note on page 4)

Complete instruments with connection heads (from page 58)			Add.-No.
+ Type BBK	No. -11	+ Type DAN-S	No. -14
+ Type BBG	No. -12	+ Type DANH	No. -15
+ Type DAN	No. -13	+ Type DANH-S	No. -16
Resistor in accuracy classes			
+ A acc. to DIN EN 60751			No. -01
+ AA acc. to DIN EN 60751			No. -02
Head transmitters (from page 60)			
+ With 45 mm long open wire ends for connection of a head transmitter subsequently			No. -31
+ With head transmitter type 1 (fixed range, low-cost version)*			No. -32
+ With head transmitter type 2 (programmable, elect. insulation)*			No. -33
+ With head transmitter type 3 (as type 2, but EEx-Version)*			No. -34

* Name the desired measuring range.

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижегород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47