

Термопара ТЕ-ВВ-к

Технические характеристики

По вопросам продаж и поддержки обращайтесь:

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884


Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47

TE-BB-k

SCREW-IN THERMOCOUPLE SIMILAR DIN 43772


FORM 2G, WITH EXCHANGEABLE INSERT



- COMPLETE INSTRUMENTS
- SPECIFICATION OF THE STANDARD DESIGN:
- + Connection head Type B at light metal with cable gland M 20 x 1,5 (acc. to DIN EN 50446)
 - + Thermowell at stainless steel 1.4571
 - + Mounting bush G 1/2 at stainless steel 1.4571
 - + Immersion length EL and thermowell Ø acc. to table
 - + Measuring insert with mineral insulated sheathed cable (bendable) stainless steel sheath with constant diameter
 - + Thermocouple NiCr-Ni (Type K) or Fe-CuNi (Type J); simplex or duplex
 - + Tolerance acc. to DIN EN 60584 class 2
 - + Measuring point insulated
 - + Connection via ceramic terminal block with connection pins
 - + Range -100 °C to 600 °C

Thermowell ø mm		Material	Nominal Length in mm	Insert ø mm	Insert Length in mm	Type K		Type J	
		1.4571 X6CrNiMoTi 17-12-2				simplex	duplex	simplex	duplex
TE- BB-k-9	9		160	6	205	8614001	8614101	8614201	8614301
			250		295	8614002	8614102	8614202	8614302
			400		445	8614003	8614103	8614203	8614303
TE- BB-k-11	11		160	6	205	8614011	8614111	8614211	8614311
			250		295	8614012	8614112	8614212	8614312
			400		445	8614013	8614113	8614213	8614313
TE- BB-k-12	12		160	6	205	8614021	8614121	8614221	8614321
			250		295	8614022	8614122	8614222	8614322
			400		445	8614023	8614123	8614223	8614323
TE- BB-k-14	14		160	8	205	8614031	8614131	8614231	8614331
			250		295	8614032	8614132	8614232	8614332
		400	445		8614033	8614133	8614233	8614333	

- SPARE INSERTS AT BENDABLE DESIGN
- SPECIFICATION:
- + Measuring insert with mineral insulated sheathed cable (bendable) at stainless steel
 - + Temperature range -100 °C to 600 °C



	Insert Ø mm	Insert Length in mm	Type K		Type J	
			simplex	duplex	simplex	duplex
TE-ME- MI-6	6	205	8671082	8671182	8671282	8671382
		295	8671083	8671183	8671283	8671383
		445	8671088	8671188	8671288	8671388
TE-ME- MI-8	8	205	8681002	8681102	8681202	8681302
		295	8681003	8681103	8681203	8681303
		445	8681008	8681108	8681208	8681308

- OPTIONS (Order note on page 4)
- | Material | Add.-No. |
|--|----------|
| + Thermowell at stainless steel 1.4541 | No. -91 |
| Complete instruments with connection heads (from page 48) | |
| + Type BBK | No. -11 |
| + Type BBG | No. -12 |
| + Type DAN | No. -13 |
| + Type DAN-S | No. -14 |
| + Type DANH | No. -15 |
| + Type DANH-S | No. -16 |
| Head transmitters (from page 50) | |
| + With 45 mm long open wire ends for connection of a head transmitter subsequently | No. -31 |
| + With head transmitter Type 2 (programmable, elect. insulation)* | No. -33 |
| + With head transmitter Type 3 (as Type 2, but EEx-Version)* | No. -34 |

Алматы (727)345-47-04
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижегород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +(727)345-47-04

Беларусь +(375)257-127-884

Узбекистан +998(71)205-18-59

Киргизия +996(312)96-26-47